

September 11, 2019

Problem solved: make a consistent connection of long time normal diffusion as e.g. measured by NMR to some sublinear diffusion regime.

Conditions

1. Gaussian approximation is valid
2. sub/super-linear diffusion at short time is described by  $\langle r^2(t) \rangle \propto t^\beta$
3. at some transition time  $t^*$  (tstar) the short time diffusion smoothly meets the long time diffusion
4. the condition that value and slope of  $\langle r^2(t) \rangle$  match at  $t^*$  implies an offset for the mean square displacement in the long time behaviour.
5. besides the stretching exponent  $\beta$ ,  $t^*$  ( $t^*$ ) is the only additional free parameter.

After a few operation we the arrive at:

$$\langle r^2(t < t^*) \rangle = 6 \frac{t^\beta t^{*-\beta+1} D_{nmr}}{\beta} = 6 \frac{(t/t^*)^\beta (t^* D_{nmr})}{\beta} \quad (1)$$

and

$$\langle r^2(t > t^*) \rangle = 6 \frac{D_{nmr} (\beta t - \beta t^* + t^*)}{\beta} = 6 D_{nmr} [t + t^*(1/\beta - 1)] \quad (2)$$

the intermediate scattering (factor) then follows immediately from the Gaussian approximation.

$$S(Q, t) = \exp(-q^2 \langle r^2(t) \rangle / 6) \quad (3)$$

---

M. Monkenbusch, JCNS-1 , July 2015

---

Subroutine:

---

```

function diffusion_beta(t,q,Dlong,tstar,beta) result(sqrt)
!-----
!
! diffusion scattering function under Gaussian approximation
! but with subdiffusive start
!
! the physical parameters are the classic long time diffusion constant Dlong
! and a transition time tstar
! below tstar the diffusion is sub (super?) diffusive
! with  $\langle r^2 \rangle(t) \sim t^{\beta}$ 
!
! the transition is smooth (stetig 1 x differenzierbar) at tstar
! this implies that the long time diffusion is linear with an offset, which
! implicitly is controlled by the value of tstar and the smoothness condition
!
! Michael Monkenbusch, JCNS-1, June 2015
!-----
implicit none

double precision, intent(in) :: t      ! time in the time units used in the diffusion constant units
double precision, intent(in) :: q      ! "q", momentum transfer in the length units used for Dlong
double precision, intent(in) :: Dlong  ! long time diffusion constant in units consistent with t and q
double precision, intent(in) :: tstar  ! transition time between short and long time diffusion (units as t)
double precision, intent(in) :: beta   ! stretching exponent for the sublinear initial part of diffusion

double precision              :: sqrt  ! return value = intermediate scattering factor of the diffusion

double precision              :: r2

if(t < tstar) then
    r2 = 6*t**beta*tstar**(-beta+1)*Dlong/beta
else
    r2 = 6*Dlong*(beta*t-beta*tstar+tstar)/beta
endif

sqrt = exp(-q*q*r2/6d0)

! testing
! write(6, '(3F18.9)') t, r2, sqrt
! testing

end function diffusion_beta

```